

Setup of the Web-unit's email notifications

Sign in

Sign in: Username: AWMADMIN Password: awmadmin

Select menu "System settings".

Mail server configuration

Select "Communication" => "Mail Server configuration": Enter SMTP server, email address and if necessary SMTP User name and password.

SMTP-server – Email server for outgoing e-mails. In the example "XCH02.ad.ivprodukt.se" is used. (NOTE! Use the server name, not IP address.)

If you have purchased an external SMTP server service, you may need to enter username and password, these data are in such cases provided by the provider of the SMTP server

Port - Port 25 is the default port for outgoing e-mail.

Email address – The address that the email alert will be sent from. In the example "POL909_FF43D2@ivprodukt.se" is used. The entered address does not need to exist.

ding with the focus on LCC Network Mail server configuration	Communication	User Management	Diagnostics	Applications	
Mail server configu	ration				
A 	Email address:* PO	H02.ad.ivprodukt.se p Use SSL L909_FF43D2@ivpr SMTP Pop3 before SMTP	ort:* 25		
* Required fields				ок	Cancel

return to start page | Advanced Web Module Configuration Tool - V10.20 | © Siemens 2010



Email settings

Select "Email settings" => "General settings": Enter the email address that will receive the alarm, the email subject, the notification message and when the email is to be sent.

Email notification receiver – If you want the alarm-mail to be sent to multiple email addresses, enter the addresses with a ";" between. For example: <u>Erik.Exempelsson@ivprodukt.se;Erika.Exempelsson@ivprodukt.se</u>

Email notification message – Enter "%s" to get the information from Climatix.

Network Communicatio	User Management Diagnostics	Applications
Mail server configuration Email setting	SINS settings	
General settings Advanced settings		
Use Email notifications		
Email notification receiver:* Email notification subject:*	erik.exempelsson@ivpro	
Email notification subject:*	LA06 IVP	
Eman nouncation message.	*3	~
		~
Email notification trigger		
	Alarm is going into active state	
Send test Email:		
Email alarm server ID:	3	
Email Language	Language0 V	
You can use the Climatix text placeh	Ider (%s) in the email notification message to include informa	tion from the controller.
-		

return to start page | Advanced Web Module Configuration Tool - V10.20 | © Siemens 2010



Restart

Make sure that the settings for the network, in menu "Network" => "Network settings", are set.

Network Communication	User Management	Diagnostics	Applications
twork settings Modem configuration	Dial-up connections P2P co	onfiguration	
Network settings			
Device name*	POL909		
O Obtain on ID address autom			
 Obtain an IP address automa Use the following IP address 			
IP address*			
Subnet mask*	192.168.1.1	-	
Default gateway*	255.255.255.0 192.168.1.2	-	
	192.100.1.2		
<u></u>			
 Obtain the DNS server addre Use the following DNS server 			
Preferred DNS server*	8.8.8.8	_	
Alternate Diva server			
Obtain the WINS server addr			
O Use the following WINS served as a served of the serv	er addresses		
You can get IP settings assigned auto administrator.	matically, if your network sup	pports this capability. O	therwise, you need to ask your netw

return to start page | Advanced Web Module Configuration Tool - V10.20 | © Siemens 2010

When everything is completed a restart is needed. Restart is easiest made in menu: "Diagnostics" => "Reboot system".

		User Management	Diagnostics	Applications
Log files System s	ate Reboot system			
Log files				
 A history A compor Rainbow A compor compone A service 	omponents. ents history log file named its.	hich contains ongoing st omponentsError.log whi ComponentsHistory.log erviceTaskTrace.log whi	atus information. In contains information which contains ongoin	e occurred. about all errors that have occurred by th g status information about the Rainbow atus information about the services.
Reboot system	te" section, you can get inf n section allows you to reb			id Web Module.