












# Climatix Hand-held Terminal

## INFO Information







-  **Press** – shows **Start Page** in the display window
-  **No light**  
Unit stopped
-  **Solid green light**  
Normal operation
-  **Solid orange light**  
Emergency stop
-  **Flashes green**  
Start-up, night mode test, night-cooling or night-heating mode
-  **Flashes orange**  
Fire damper exercise cycle
-  **Alternating green and orange**  
Off or manual control
-  **Flashes red**  
Emergency operation, such as in the event of fire or refrigerant leakage





## Display window

-  **Alarm**
-  **Flashes red**  
Active alarm





## Navigation and confirmation

-  **OK**
-  **Turn** – changes a value
-  **Turn to the right** – moves down through the menus
-  **Turn to the left** – moves up through the menus
-  **Press** – shows a menu or confirms a value
-  **Press and hold** – shows **PIN handling**






## ESC – return

-  **ESC**
-  **Press** – shows the previous menu or cancels the current action

## Starting and stopping the unit

1. Turn navigation  until **SERVICE SWITCH** is highlighted.
2. Press navigation  to confirm.
3. Turn navigation  to the desired option:
  - AUTO** The unit starts and stops via the time scheduler or other operating functions
  - OFF** The unit stops
4. Press navigation  to confirm.





## Sign in

1. Turn navigation  until **Password enter** is highlighted.
  2. Press navigation  to confirm.
- Turn  and press navigation  until the code **1000** appears.
- Correct sign in is indicated by a key  displayed in the top left-hand corner.



Control system functions

## Alarm reset

1. Press alarm . Current alarms are listed in the display window.
2. Press alarm  again. **Acknowledge** will appear in the display window.
3. Press navigation  and select **Execute**.
4. Press navigation . The alarm is now reset.

