



# Quick Guide EcoCooler




## Control unit



### Start/Stop the EcoCooler




### Normal operation




EcoCooler in operation.

### ACA-limiting



EcoCooler in operation with limited out signal to speed controlled compressor due to high pressure.

### Alarm



EcoCooler in operation with an alarm on compressor 2. Alarm reset; press ▲ twice.